Picnic Table

28"

10"

a

b

a

e

x   **d**   **x**

18"

c

60°

9"

a

e   **f**

b

a

g

d

c

All wood is 2"x4" boards.

a = 11 × 72"
b = 2 × 28"
c = 4 × 33"
d = 2 × 52"
e = 2 × 27"
f = 1 × 20"
g = 2 × 7"

Uses about 100 2½" #8 screws.
Piece **f** length is approximate;
cut it to fit after rest of table
assembled.
Diagram not to scale!

x = ¼" bolt & nut (with washers)